


Assembly Manual for Nutcracker - Nut Crusher Steel PB0008





1. In the photo on the left, you can see all the parts of the Nutcracker - Steel Nut Crusher Steel that included in the package.

2. Place the Main Body on the Metallic Base in such a way that the notches are fastened. (Photos 2a & 2b)



3. Turn Upside - down the Main Body with the Metallic Base and screw the Nut without Head, until the Main Body stabilized to the Metallic Base. (Photos 3a & 3b)




4a



4. Place upright, the Main Body with the Metallic Base. Put the screws with their washers in the notches and tighten the butterflies screw tightly.

(Photos 4a, 4b & 4c)

4b




4c



5. Place the Metallic Face Plate in the back notches of the Main Body. (Photos 5a & 5b)



5a



5b



6. Place the Metallic Lever in the front notches of the Main Body. (Photos 6a & 6b)



7. Place the Adjusting Bolt at the back of the Main Body and screw it according to the size of the nuts you will break. The Adjusting Bolt tightens the walnuts or other nuts until they lock between the Metallic Lever and the Metallic Face Plate. (Photos 7a, 7b, 7c, 7d & 7e)





8. To fix the Nutcracker - Nut Crusher Steel, on the table or the workbench, just screw it, through the two holes in its base. Now you are ready to use it!



9. In case you do not want to open holes on your table or on your workbench, you can use the Clamps for table mounting of the Nutcracker - Nut Crusher Steel.